


CLUTCH BELL 1/10 HOLDER (#190540)


STEP

1



STEP

2





STEP

3

CENTAX PINION TOOL 1/10 (#190542)

NOTE: The Centax Pinion Tool 1/10 (#190542) only can be used with:

- 804381 Centax-3 gear-pinion alu 15t wc V2
- 804382 Centax-3 gear-pinion alu 16t wc V2
- 804383 Centax-3 gear-pinion alu 17t wc V2
- 804384 Centax-3 gear-pinion alu 20t wc V2
- 804385 Centax-3 gear-pinion alu 21t wc V2
- 804386 Centax-3 gear-pinion alu 22t wc V2
- 804387 Centax-3 gear-pinion alu set wc (6) V2



Disassembling the pinions