


CLUTCH BELL 1/8 HOLDER (#190541)


STEP

1



STEP

2




STEP

3

CENTAX PINION TOOL 1/8 (#190543)

NOTE: The Centax Pinion Tool 1/8 (#190543) only can be used with:

- 903640 Centax gear-pinion alu 18T XLI
- 903641 Centax gear-pinion alu 19T XLI
- 903642 Centax gear-pinion alu 20T XLI
- 903643 Centax gear-pinion alu 23T XLI
- 903644 Centax gear-pinion alu 24T XLI
- 903645 Centax gear-pinion alu 25T XLI
- 903646 Centax gear-pinion alu set XLI (6)



Disassembling the pinions

